



User instructions for System 200 airspa (AS200)



The system is controlled in a 4 step sequence from the LED control on the bath.

1. Blower activated on high speed (L.E.D illuminated)
2. Medium speed (L.E.D illuminated)
3. Low speed (L.E.D illuminated)
4. Blower switches off (L.E.D turns off)

Automatic stop - The blower stops automatically 30 minutes after the control has last been used.

Hygiene Management - 30 minutes after manual and automatic stop, the dry blowing programme will start. The blower starts at high speed for 2 seconds, then falls to low speed, then slowly rises to high speed again within 30 seconds and stays at that speed for 4 1/2 minutes. Under countdown and execution of the programme the L.E.D will flash.